

4-WAY ADJUSTABLE MINI OSCILLATING SPRINKLER



Assembly

Simply attach the sprinkler head to the top of the base and connect to your hose





Set-Up with Quick Connect

Attach the sprinkler head to the top of the base. Connect the Product Adapter to the base of the sprinkler. Attach the lockable Quick Connect to the end of the hose and simply snap in the hose to the sprinkler to begin using.










Simply remove the end-cap and attach another hose to connect an additional sprinkler if needed.












Sliding tabs control the width (up to 59ft. (18m))










Range Control


Push down tabs control the length (up to 36.1ft.(11m))





Water Flow Control

Allows adjustment of overall watering area.



360° Rotation Adjustment

Allow simple incremental angle adjustments without moving the sprinkler and hose.

△ CAUTION △

- -For outdoor use with cold water only
- -Do not spray near electrical connections
- -When not in use, rinse the tool with water to remove most of the dirt, dry your tool, and store indoors

This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov

The Quick Connect Adapter (2 pcs) and Hose Connector with Water Stop (1 pc) simplify your watering experience. Simply attach the connector at the end of your hose. Then, connect the adapters to your watering tools. Interchange various tools in a snap without turning off the water as the adapter will stop the water flow. No more kinking or hose twisting as the adapter allows the hose to swivel 360 degrees.



