

# REVOLVING SPRINKLER W/ WEIGHTED BASE

Adjustable angle nozzles vertical to 45° creating twirling

Center fountain head nozzle creating fountain effect

Additional extension connection

Hose connector

Added weight in base for increased stability

**Quick Connect Adapter fits most brands of garden hoses**



**Perfect for watering lawns and gardens**



Agricultural



Horticultural



Vegetables



Fruits



Lawn



Garden

Water your lawn and enjoy a show with the Eden 360° Rotating Sprinkler with Weighted Base. The 3-arm design twirls and provides a dancing water effect that is fun to watch and provides ideal watering for your lawn or garden. It's easy to set up, easy to adjust and has added weight in the base for stability.

Multi-purpose in design for all of your watering needs. From lawn irrigation, greenhouse watering, area cooling and more. The speed of the rotation varies according to the angle of the arm nozzles. From 90° (no rotation) to 45° (full rotation), you can adjust the rotation speed to suit your needs.

Attach the sprinkler to the hose connector and turn on the faucet to start watering a large circular area. Just the pressure of your household water supply can achieve automatic garden/lawn irrigation. It can be connected in series with other units to increase the reach (max. suggested 3).


## Features & Benefits-

- Easy to use and setup
- Durable base design with added weights provides stability
- Made from premium ABS material for strength
- 360° rotating spray
- 15 nozzle points provide a dancing fountain watering effect
- Watering without wasting water resources
- Easily adjust for smaller or larger watering areas
- Capable of watering up to 1500 sq. ft (140 m<sup>2</sup>) based on 30 PSI

# For setup, you can choose Method A or B


## Method A

Simply attach the sprinkler to the top of the base  
*(Do not overtighten)* and connect to your hose.



## Method B

Connect the adapter to the base, attach the hose with the quick lockable connector, then simply snap in the water hose to the completed assembly.



To extend, simply remove the end-cup and attach another hose and connect another sprinkler.

### WARNING:

*Intended for outdoor agricultural or horticultural use only. This is not a toy. Severe electrical shock could result if water is sprayed into outlets or sources of electrical current. Do not use water more than 115°F (46°C). Do not use when the ambient air temperature is less than 40°F (4.5°C). When not in use, drain and store indoors away from freezing temperatures.*

**⚠WARNING:** This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

QUESTIONS? CONCERNS?

**We're here to help!**

Contact our reliable, US-based Customer Service

[support@edengarden.com](mailto:support@edengarden.com)

1+ 866-521-7718

The Quick Connect Adapter (2 pcs) and Hose Connector with Water Stop (1 pc) simplify your watering experience. Simply attach the connector at the end of your hose. Then, connect the adapters to your watering tools. Interchange various tools in a snap without turning off the water as the adapter will stop the water flow. No more kinking or hose twisting as the adapter allows the hose to swivel 360 degrees.

