

added filter prevents

clogging the sprinkler

REVOLVING SPRINKLER



*These instructions are adaptable to all of the EDEN Revolving Sprinklers model# 94135EDAMZ, 94136EDAMZ and 94137EDAMZ

Assembly - Connect the Hose

Use the Quick Connect System to connect and disconnect the sprinkler from the hose easily. Connect the Product Adapter to the base of the sprinkler. Attach the lockable Quick Connect to the end of the hose, then snap in the hose to the sprinkler to begin using.

Use the additional product adapter to switch between your other watering tools (i.e., nozzles, wands, etc.) even with the water running.

Note: If you are not using the Quick Connect System, connect the sprinkler directly to the hose.









Features & Benefits:

- · Efficiently water your lawn up to 2800 sq ft (260 sq m)
- · Fountain-style watering of your yard, garden, and plants
- · Turn on the hose and watch the carousel turn on its own
- · Constructed from durable materials for outdoor use
- · Great for keeping cool on a hot summer day

· Multi-purpose: The sprinkler can be used for lawn irrigation, garden watering, and cooling.

NOTE: This product is not intended to be used as a child's toy





Warranty:

Eden offers a 2-year limited manufacturer warranty. To submit a warranty claim, please submit a warranty claim on our website https://edengarden.com/contact/

△ CAUTION △

- -For outdoor use with cold water only
- -Do not spray near electrical connections
- -When not in use, rinse the tool with water to remove most of the dirt, dry your tool, and store indoors

▲ WARNING: This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov.

The Quick Connect Adapter (2 pcs) and Hose Connector with Water Stop (1 pc) simplify your watering experience. Simply attach the connector at the end of your hose. Then, connect the adapters to your watering tools. Interchange various tools in a snap without turning off the water as the adapter will stop the water flow. No more kinking or hose twisting as the adapter allows the hose to swivel 360 degrees.



