



94625EDAMZ

PRO METAL 4-PATTERN THUMB-CONTROL TURBO[®] EXTENSION WATERING WAND



REACHING CHALLENGING WATERING TASKS

Make watering hard-to-reach places easier with the 4-pattern Turbo Extension Watering Wand. All done like a PRO. The 40- inch wand offers an extended reach up to 66 inches to go further and clean hard-to-reach areas like under the car or above the windows. The 270° pivoting head adjusts the spray angle to get water exactly where you need it.

Forget about using expensive energy pressure washers when you can have a handheld pressure spraying wand which cleans with a mini twisting pattern (take a video on your smartphone to view the twisting effect!). The Turbo wand cleans surfaces by using a precise compact stream of water which twists as it cleans. The circular twisting pulse motion makes dirt a thing of the past.





Pick from four spray patterns to clean your car with the Turbo spray then turn to water your garden with the Cone setting. The durable, rubberized, easy-grip, ergonomic handle fits perfectly in the hand. The convenient thumb control reduces fatigue and allows you to turn the water off with one simple motion to prevent wasting water. It resists damage and rust and stands up to abuse for years of reliable and dependable performance.






Turbo: Great for large surface cleaning such as gutters, driveways, windows, decks, and pavement or for deep water penetration of hard soil.

Jet: Creates precise narrow strips and reaches a far distance. Useful for cleaning soffits, porches, balconies, lawnmowers, snowblowers, quadrunners, etc...

Flat: Creates a wide spray of flat water. Useful to disperse and sweep leaves and dirt.

Cone: Gives you a circle of spray so that you can water a ring of plants all at once.





WARNING:

Intended for outdoor use only. This is not a toy. Severe electrical shock could result if water is sprayed into outlets or sources of electrical current. Do not use water more than 115°F (46°C). Do not use when the ambient air temperature is less than 40°F (4.5°C). When not in use, drain and store indoors away from freezing temperatures.

WARNING: This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov.

QUESTIONS? CONCERNS?

We're here to help!

Contact our reliable, US-based Customer Service

support@edengarden.com

1+ 866-521-7718

The Quick Connect Adapter (2 pcs) and Hose Connector with Water Stop (1 pc) simplify your watering experience. Simply attach the connector at the end of your hose. Then, connect the adapters to your watering tools. Interchange various tools in a snap without turning off the water as the adapter will stop the water flow. No more kinking or hose twisting as the adapter allows the hose to swivel 360 degrees.

